

AUNTIES TWO

AT626 PERFECTLY PRACTICAL BAG

Hollman KaBloom Panel

Special Cutting Instructions for the Perfectly Practical Bag

In lieu of Fabric A, use two KaBloom panels (as shown below), one for the front and one for the back.

Follow pattern requirements and cutting instructions for FABRIC B and C, except as noted below. Shapes in diagram are not drawn to size.



- (A) Fussy cut the 2 teal squares for the OUTSIDE POCKETS (9" wide x 8" tall) with the center of the flower in the center of the pocket. Use leftover from Step C for POCKET BINDING.
- (B) Fussy cut 2 big blue squares for OUTSIDE POCKET LININGS (9" wide x 8" tall). These will not show on the outside.
- (C) Add an outside pocket on a large square. Make sure the bottom edge of the pocket is at least 14" from top edge of the square. Once you have it where you want it, draw a horizontal chalk line all the way across the panel in line with the bottom edge of the pocket (white dashed line).

With chalk, draw a 10" wide x 14" tall rectangle for the CENTER panel (orange) centered on the line drawn above. Also draw a 6½" wide x 14" tall rectangle to the left and one to the right for the SIDES (green).

Place the pocket back on the center panel to make sure you are ok with the position. Now the time to make any changes! (Note: There will be a seamline between the center panel and the sides.)

Cut out your rectangles. Additionally, for the sashing, cut a 1¼" wide x 14" tall strip (red). Do the same with the second large square, EXCEPT do not cut any sashing.

FOLLOW PATTERN DIRECTIONS TO COMPLETE THE BAG!!

